



Thermal Vacuum Testing of a Multi-Evaporator Miniature Loop Heat Pipe

**Jentung Ku, Laura Ottenstein
NASA/GSFC
Greenbelt, Maryland
Jentung.Ku-1@nasa.gov**

**Hosei Nagano
NASA Visiting Researcher
JAXA/ISAS
Kanagawa, Japan**

**2008 International Two-Phase Thermal Control Technology Workshop
May 13-15, 2008, Noordwijk, The Netherlands**



Outline

- **Introduction/Background**
- **Test Article**
- **Thermal Vacuum Test Set-up**
- **Tests Performed**
- **Experimental Results**
- **Summary and Conclusion**





Introduction/Background

- Under NASA's New Millennium Program Space Technology 8 Project, four experiments are being developed for future small system applications requiring low mass, low power, and compactness.
- GSFC is responsible for developing the Thermal Loop experiment, which is an advanced thermal control system consisting of a miniature loop heat pipe (MLHP) with multiple evaporators and condensers.
- The objective is to validate the operation of an MLHP, including reliable start-ups, steady operation, heat load sharing, and tight temperature control over the range of 273K to 308K.
- An MLHP Breadboard has been built and tested for 1200 hours under the laboratory environment and 500 hours in a thermal vacuum chamber.
- Results of the TV tests are presented here.




LHP Basics



Cross Sectional View of Evaporator Core


- No external pumping power and no moving parts
- Passive and self-regulating
- Operating temperature can be controlled at the desired set point
- State-of-the-art
 - Single evaporator
 - 1 inch (25.4mm) wick
 - Heating the CC only, no active cooling






Thermal Loop Concept Description

- **Miniature Loop Heat Pipe**
 - Two parallel evaporators
 - Two parallel condensers
 - Compensation chambers (CC)
 - Fluid reservoir
 - Flow Regulator
 - Prevents vapor blow through when only one condenser is fully utilized
 - Working Fluid
 - Anhydrous ammonia
- **Instrument Simulators**
 - Simulate instruments or electronic box
- **Thermoelectric Converters (TECs)**
 - Maintain CC saturation temperature
 - Variable set point control
- **Coupling Blocks**
 - Reduce control heater power requirements by transferring heat from vapor to return liquid






Pictures of MLHP Breadboard 2




Overall View



**Close View of
Evaporator/CC Section**



ST8 Breadboard 2 – TC Locations





Test Setup and Instrumentation

- **Each evaporator has a 400-gram aluminum mass attached.**
- **A cartridge heater was inserted into each thermal mass to provide 1W to 150W of heat load.**
- **A cooling block was attached to each thermal mass to provide a heat sink for heat load sharing tests. The coolant temperature and flow rate were varied during the test.**
- **A thermoelectric converter (TEC) was attached to each CC. The other side of the TEC was connected to the evaporator through a copper strap.**
- **Each TEC was connected to a separate bi-polar power supply.**
- **More than 100 type T thermocouples were used.**
- **Data acquisition system**
 - **Two dataloggers**
 - **Two PCs**
 - **Collect, display, and store data every second.**
- **Labview software was used for command and control of test conditions.**



Problem Encountered During Testing

- **A problems with the test set-up led to sporadic data drops.**
 - **Each time this happened, all temperatures read 282K for a single data scan.**
 - **The TECs responded to this erroneous reading, changing the saturation temperature.**
 - **As a result, the CC temperature fluctuated about 1K for a few minutes until stable temperatures were reestablished.**
- **In spite of this problem, the TECs demonstrated their abilities to bring the CC temperature quickly to the desired set point temperature.**



Tests Performed

- **Start-up**
- **Operating Temperature Control**
 - **TECs and electrical heaters**
 - **Power cycle**
 - **Sink temperature cycle**
 - **CC temperature change**
- **Heat Load Sharing**
- **Flow Regulator Function**
- **TEC Power Savings**
 - **Effects of Coupling Blocks on CC Control Heat Power**
- **Demonstrated more than 500 hours of LHP operation under a wide range of operating conditions in a thermal vacuum environment.**




Start-up Tests

- **51 start-up tests were conducted. All were successful.**
 - **Start-up was indicated by the rise of the vapor line temperature and the drop of the liquid line temperature.**
- **CC temperature: 0, 1 or both CCs were controlled between 258K and 308K**
- **A heat load of 5W to 50W was applied to one evaporator, independent of the heat load to the other evaporator, i.e. even and uneven heat loads**
- **Temperatures of the two condenser sinks varied between 203K and 273K, independent of each other**



Start-up 308K/308K, 0W/50W


- With 50W to E2, Mass2 and E2 temperature reached the set point quickly.
- E1 began to share heat after loop started.






Start-up 293K/293K, 0W/5W

- 2.5K superheat on E2 at start-up
- E1 shared heat after loop started.






Start-up

No control/293K, 50W/5W

- E1 was flooded prior to start-up.
- E1 reached set point temperature first and started the loop with 7K superheat.






Saturation Temperature Control

- **The loop operating temperature could be controlled by controlling the temperature of one or both CCs.**
- **The loop operating temperature could be controlled within $\pm 0.5\text{K}$ using TECs or electrical heaters.**
- **The loop operating temperature could be changed while the loop was operating.**
- **Using TECs, the loop operating temperature could be controlled below the ambient temperature and below the loop's natural operating temperature.**



Power Cycle

- CC1/CC2= 293K/293K, C1/C2 sink = 173K/173K
- E1/E2 power = 75W/0W, 50W/25W, 25W/50W, 0W/75W, 5W/50W, 50W/5W
- The loop operating temperature was maintained within $\pm 0.5\text{K}$ of the 298K set point temperature.






CC Set Point Change

- C1/C2 sink = 223K/223K. E1/E2 power = 10W/10W.
- CC1/CC2=293K/293K, 288K/288K, 283K/283K, 278K/278K, 273K/273K, NC/NC
- TECs enabled CC1/CC2 to control the loop saturation temperature below its natural operating temperature.


ST8 CETDP LHP TV Test 3-7-06





Heat Load Sharing


- CC1/CC2 = 303K/NC, E2 power = 50W constant, C1/C2 sink = 203K/243K
- E1 coolant flow rate = 0.15 gpm
- E1 coolant temperature = 283K/288K/293K/298K/303K/308K
- As coolant temperature reached 303K and 308K, E1 received heat from the coolant and was in its normal operation (shared negative heat)





Flow Regulator Test

- E1/E2 power = 30W/10W constant. CC1/CC2 = 293K/293K
- C1/C2 sink = 223K/223K, 293K/223K, 298K/223K, 223K/223K, 223K/293K, 223K/298K, 223K/223K
- Both sides of the flow regulator worked properly to stop vapor.






TEC Power Savings Test

- **Thermal Loop design incorporates coupling blocks and TECS to reduce control heater power requirements. Test were conducted using electrical heaters and TECs.**
 - **Quantify amount of power savings**
- **Power to E1/E2: 10W/10W, 20W/10W, 30W/10W, 40W/10W, 50W/10W, 60W/10W, 70W/10W.**
- **CC1/CC2 set point: 308K(EH)/308K(TEC), 308K(TEC)/308K(TEC)**
- **Number of coupling blocks: 0, 2 and 3.**
 - **Affects temperature of returning liquid**
 - **Affects control heater power requirement**



TEC Power versus Electrical Power

- TECs reduced control heater power by more than 60% compared to electrical heaters.
- Coupling blocks were also effective in reducing the control heater power.
- Combination of coupling blocks and TECs yielded significant power savings.
- Ambient tests under various sink temperatures and 0, 2, 3, 4 blocks showed similar power savings.






Summary

- The MLHP demonstrated more than 500 hours of operation under a wide range of operating conditions in a thermal vacuum chamber.
- One hundred percent success rate of start-up: turn-key start-up with TECs.
 - CC temperature: 0, 1 or both CCs were controlled between 258K and 308K
 - Heat load between 5W and 50W to either one evaporator independently
- Operation
 - The LHP operating temperature was controlled within $\pm 0.5\text{K}$ of the desired set point
 - Stable LHP operation at all times over the full range of heat loads and sink temperatures
 - Demonstrated heat load sharing between the two evaporators
- TEC for temperature control
 - Provided both heating and cooling
 - The loop operated below natural operating temperature
 - Saved control heater power by $> 50\%$ compared to electric heaters




Protoflight MLHP for TRL 6 and TRL 7 Validation





MLHP Module Concept for TRL 7 Validation (view from Spacecraft)





Thermal Loop Capabilities

- **Turn-key start-up using TECs**
- **Fine temperature control at any temperature between 273K and 308K**
- **Control temperature can be varied while operating.**
- **Thermal bus for multiple instruments or heat dissipating locations**
 - **Any power distribution between two heat sources up to the maximum total load, including negative loads (heat load sharing) for one load.**
- **100W+ heat transport limit**
- **Heat dissipation to radiators exposed to different thermal environments.**
 - **Will continue to operate as long as one radiator can dissipate entire load, even if other radiator has a net heat gain.**



QUESTIONS?